Go Direct[®] Thermocouple Amplifier (Order Code GDX-TCA)



Use Go Direct Thermocouple Amplifier to collect data from

K, J, or T type thermocouple wires (not included). Used in conjunction with our K-type wire, it can measure temperature in the range of -200° C to 1400° C and can be used for any of the following experiments:

- Study how the temperature inside a Bunsen burner flame varies with position.
- Compare the temperatures of different flames (candles *vs.* Bunsen burner).
- Check the calibration of ovens.
- Experimentally determine the melting point of copper, bismuth, or other solids.
- Measure the temperature of dry ice or liquid air.

Note: Vernier products are designed for educational use. Our products are not designed nor are they recommended for any industrial, medical, or commercial process such as life support, patient diagnosis, control of a manufacturing process, or industrial testing of any kind.

What's Included

- Go Direct Thermocouple Amplifier
- Micro USB Cable

Compatible Software and Interfaces

See **www.vernier.com/manuals/gdx-tca** for a list of software compatible with Go Direct Thermocouple Amplifier.

Quick Start: Vernier Graphical Analysis[®] and Bluetooth[®]

- 1. Connect a thermocouple wire to the amplifier. Ensure the thermocouple wire is securely connected to the thermocouple amplifier box with the + and symbols aligned.
- 2. Charge your sensor for at least 2 hours before first use.
- 3. Turn on your sensor. The LED will blink red.
- 4. Launch Graphical Analysis, then click Sensor Data Collection.
- Select your sensor from the list. The sensor ID is located on the sensor label near the bar code. Note: If you don't see a list of available sensors, click WIRELESS. After selecting your sensor, click Pair.
- 6. This is a multi-channel sensor. Click **SENSOR CHANNELS** and select the channel(s) you want to use.
- 7. Click DONE. You are now ready to collect data.

Using other Vernier data-collection apps or want to connect via USB?

$Visit \ \textbf{www.vernier.com/start-go-direct}$

Note: This sensor also works with LabQuest 2 and LabQuest 3; it does not work with the original LabQuest.

Charging the Sensor

Connect Go Direct Thermocouple Amplifier to the included Micro USB Cable and any USB device for two hours.

You can also charge up to eight Go Direct Thermocouple Amplifiers using our Go Direct Charge Station, sold separately (order code: GDX-CRG). An LED on each Go Direct Thermocouple Amplifier indicates charging status.

Charging	Orange LED next to battery icon is solid while sensor is charging.
Fully charged	Green LED next to battery icon solid when sensor is fully charged.

Powering the Sensor

Turning on the sensor	Press button once. Red LED indicator flashes when unit is on.
Putting the sensor in sleep mode	Press and hold button for more than three seconds to put into sleep mode. Red LED indicator stops flashing when sleeping.

Connecting the Sensor

See the following link for up-to-date connection information:

www.vernier.com/start/gdx-tca

Connecting via Bluetooth Wireless Technology

Ready to connect	Red LED flashes when sensor is powered and ready to connect.
Connected	Green LED flashes when sensor is connected via Bluetooth wireless technology.

Connecting via USB

Connected via USB, data collection software is not running	Red LED flashes when sensor is powered and ready to connect.
Connected via USB, data collection software is running	Green LED is solid when connected to the software via USB.

Identifying the Sensor

Use the Identify feature to flash the LED on the sensor that is connected via Bluetooth wireless technology. In Graphical Analysis, Identify is accessed from Sensor Information. In LabQuest App, Identify is accessed by tapping the sensor meter, then tapping Go Direct.

Using the Product

Connect the sensor following the steps in the Quick Start section of this user manual.

The thermocouple wire is insulated by a high-temperature glass that has a lower maximum temperature (704°C, 1300°F) than the wire itself (1400°C, 2552°F). Therefore, in use, place only the tip of the wire in the heat source and keep the insulation out of direct contact with the heat source.

Channels

Go Direct Thermocouple has three sensor channels:

- K-type (default)
- J-type
- T-type

Note: The K-type channel is the default channel for this sensor. All channels are mutually exclusive. In order to collect data from the other temperature channels, you must also attach the applicable corresponding thermocouple wire to the amplifier box.

Calibrating the Sensor

You should not have to perform a new calibration when using Go Direct Thermocouple Amplifier in the classroom. The sensor is custom calibrated before it is shipped. If you wish to calibrate the sensor, you can conduct a one-point calibration in the software. This calibration will be stored automatically to the sensor.

Specifications

Temperature range	–200°C to 1400°C
Typical accuracy	$\pm 2.2^{\circ}$ C or 0.75% of reading, whichever is greater
Compatible thermocouple wires	K-type, J-type, and T-type
Wireless Specification	Bluetooth 4.2
Battery	300 mA Li-Poly

Care and Maintenance

Battery Information

Go Direct Thermocouple Amplifier contains a small lithium-ion battery. The system is designed to consume very little power and not put heavy demands on the battery. Although the battery is warranted for one year, the expected battery life should be several years. Replacement batteries are available from Vernier (order code: GDX-BAT-300).

Storage and Maintenance

To store Go Direct Thermocouple Amplifier for extended periods of time, put the device in sleep mode by holding the button down for at least three seconds. The red LED will stop flashing to show that the unit is in sleep mode. Over several months, the battery will discharge but will not be damaged. After such storage, charge the device for a few hours, and the unit will be ready for use.

Exposing the amplifier box to temperatures below -15° C or over 45° C will damage it. Additionally, temperatures over 35° C (95° F) will reduce the battery's lifespan. If possible, store the device in an area that is not exposed to temperature extremes.

Water Resistance

Important: Go Direct Thermocouple Amplifier is neither waterproof, nor is it water resistant and should never be immersed in water.

If any liquid gets into the device, immediately power the unit down (press and hold the power button for more than three seconds). Disconnect the sensor and charging cable, and remove the battery. Allow the device to dry thoroughly before attempting to use the device again. Do not attempt to dry using an external heat source.

Note: Damage due to liquids is not covered under warranty.

How the Sensor Works

Thermocouples make use of a property that occurs when two wires composed of dissimilar metals are joined at both ends. When one of the joined ends is heated, a continuous current is created and flows in a thermoelectric circuit. The small open-circuit voltage of this circuit (known as the Seebeck voltage) is a function of the junction temperature and the composition of the two metals. (Go Direct Thermocouple Amplifier uses a K-type thermocouple wire with chromel and alumel.) By measuring the voltage, the temperature at the joined end can be calculated.

Measuring the Seebeck voltage requires connecting a voltmeter's leads to the thermocouple wires. This new junction creates an additional thermocouple. In order to compensate for this new thermocouple, we use a method called cold-junction compensation. This method requires knowing the temperature at the new junction. Traditionally, these junctions were held at 0°C in an ice bath. The Go Direct Thermocouple performs a direct measurement of the temperature of the reference junction with an integrated-circuit amplifier.

Troubleshooting

The thermocouple wire is installed properly and ready to use if the LED next to the check symbol turns green. If it turns red, your connection is not secure or your wire may be damaged.

For troubleshooting and FAQs, see www.vernier.com/til/7738

Repair Information

If you have followed the troubleshooting steps and are still having trouble with your Go Direct Thermocouple Amplifier, contact Vernier Technical Support at support@vernier.com or call 888-837-6437. Support specialists will work with you to determine if the unit needs to be sent in for repair. At that time, a Return Merchandise Authorization (RMA) number will be issued and instructions will be communicated on how to return the unit for repair.

Accessories/Replacements

ltem	Order Code
Micro USB Cable	CB-USB-MICRO
Type-K Thermocouple Wire	KWIRE-TCA
Go Direct 300 mAh Replacement Battery	GDX-BAT-300

Warrantv

Warranty information for this product can be found on the Support tab at www.vernier.com/gdx-tca

General warranty information can be found at www.vernier.com/warranty

Disposal

When disposing of this electronic product, do not treat it as household waste. Its disposal is subject to regulations that vary by country and region. This item should be given to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring that this product is disposed of correctly, you help prevent potential negative consequences on human health or on the environment. The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, contact your local city office or your disposal service.

Battery recycling information is available at www.call2recycle.org

Do not puncture or expose the battery to excessive heat or flame.

The symbol, shown here, indicates that this product must not be disposed of in a standard waste container.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference and

(2) this device must accept any interference received, including interference that may cause undesired operation

RF Exposure Warning

The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

IC Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Industry Canada - Class B This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of Industry Canada. Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.

RF exposure warning: The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'appareil doit accepter tout interférence radioélectrique, même si cela résulte à un brouillage susceptible d'en compromettre le fonctionnement.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel interférant-brouilleur: "Appareils Numériques," NMB-003 édictée par industrie Canada. L'utilisation est soumise aux deux conditions suivantes:

(1) cet appareil ne peut causer d'interférences, et

(2) cet appareil doit accepter toutes interférences, y comprises celles susceptibles de provoquer un disfonctionnement du dispositif.

Afin de réduire les interférences radio potentielles pour les autres utilisateurs, le type d'antenne et son gain doivent être choisie de telle façon que l'équivalent de puissance isotrope émis (e.i.r.p) n'est pas plus grand que celui permis pour une communication établie.

Avertissement d'exposition RF: L'équipement est conforme aux limites d'exposition aux RF établies pour un environnement non supervisé. L'antenne (s) utilisée pour ce transmetteur ne doit pas être jumelés ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Note: This product is a sensitive measurement device. For best results, use the cables that were provided. Keep the device away from electromagnetic noise sources, such as microwayes, monitors, electric motors, and appliances



Vernier Science Education 13979 SW Millikan Way • Beaverton, OR 97005-2886 Toll Free (888) 837-6437 • (503) 277-2299 • Fax (503) 277-2440 info@vernier.com • www.vernier.com

Rev. 7/9/2024

Go Direct, Vernier Graphical Analysis, LabQuest, and other marks shown are our trademarks or registered trademarks in the United States. All other marks not owned by us that appear herein are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by us.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Vernier Science Education is under license. Other trademarks and trade names are those of their respective owners.

